


# MANUAL

## Solenoid Valve

SKU SLD-VV



### FEATURES



Tough Construction



Precise Control



Reliable Performance



Apex® Compatible



Easy Installation



Versatile



Efficient Operation

### FUNCTIONS

Our Solenoid Valve was designed to control the flow of water or gases in your aquarium setup. It is compatible with the Neptune® Systems equipment that have the 1-Link type connector available. The operation of the valve can be controlled using the Fusion app.

### INSTALLATION INSTRUCTIONS

1. Connect the Solenoid Valve to any available 1-Link port on any of your Neptune Systems equipment
2. Control the solenoid valve operation using the Fusion app

This is a very basic example of how to add and control your solenoid valve. More information on how to program your solenoid valve can be obtained at the Neptune forum at: <https://forum.neptunesystems.com/forum.php>

### SAFETY GUIDELINES

Although the solenoid valve is safe for the saltwater aquarium environment, care should be taken to keep it always dry and as far away from saltwater as possible to avoid corrosion which can reduce the life span of your equipment dramatically. Even if it doesn't get wet directly, saltwater sea air is enough to corrode your solenoid valve over time. Install it securely in a clean and dry location.

### FREQUENTLY ASKED QUESTIONS

- Q . Can I use it with saltwater?**
- A. No, the solenoid valve should NEVER be used with saltwater.
- Q . What can I use it with?**
- A. You can use it with freshwater, like RODI and gases, like air.

### WARRANTY

The solenoid valve is guaranteed against manufacturing defects. If you need product support please visit <https://reefoutfit.com/contact-us/>

